



**No. Part Description**

- 1 — V block discharge clamp
- 2 — Locking block
- 3 — Tubing clamp arm
- 4 — Tubing clamp
- 5 — Clevis pin
- 6 — Handle
- 7 — Transmission cover
- 8 — Motor
- 9 — Clutch
- 10 — Well casing hook
- 11 — Support block
- 12 — Front mechanical cover
- 13 — Top block
- 14 — Sliding block
- 15 — Guide rails
- 16 — Long crank arm
- 17 — Short crank arm
- 18 — Mounting block
- 19 — Back mechanical cover
- 20 — Gear box base
- 21 — Transmission
- 22 — Base
- 23 — Ratchet belt

**waterra**

Groundwater Monitoring Equipment & Supplies

**PowerPump-2 Parts Diagram**



Waterra Pumps Limited 5200 Dixie Road, Unit 44  
 Mississauga, ON Canada L4W 1E4  
 email: sales@waterra.com  
 web: www.waterra.com  
 tel: 905.238.5242 • fax: 905.238.5704